



Instructional Manual

AA-15 Series





## 10 Commandments of Gun Safety

1. TREAT EVERY GUN AS IF IT WERE LOADED.
2. ALWAYS TAKE CARE IN WHERE YOU ARE POINTING YOUR MUZZLE.
3. BE SURE THAT THE BARREL IS CLEAR FROM ANY OBSTRUCTIONS.
4. WHEN HANDLING THE GUN MAKE SURE THAT YOU ARE ALWAYS IN CONTROL OF THE MUZZLE.
5. BEFORE FIRING ALWAYS BE SURE OF YOUR TARGET, MAKE SURE THAT THERE IS NO CHANCE TO HIT AN UNINTENDED TARGET.
6. NEVER POINT THE GUN AT ANY OTHER PERSON.
7. NEVER CLIMB A FENCE OR TREE WHILE HOLDING YOUR GUN, SET IT ON THE GROUND FIRST OF HAVE A FRIEND ASSIST YOU.
8. BE MINDFUL NOT TO SHOOT AT FLAT SURFACES AS RICOCHETS ARE POSSIBLE AND CAN LEAD TO PHYSICAL INJURY OR UNINTENDED DAMAGE.
9. BE SURE TO STORE THE GUN IN A SAFE PLACE THAT CHILDREN CANNOT REACH, NEVER LEAVE THE BATTERY PLUGGED INTO THE GUN.
10. NEVER CONSUME ALCOHOLIC BEVERAGES WHILE HANDLING OR FIRING THE GUN.



## Safety Rules-Guidelines

Please read the entire Adaptive Armament manual before operating the airsoft gun. This manual covers important safety, operational, and maintenance topics. It is important that the user reads and understands the manual in order to safely handle and operate the airsoft gun. Failure to follow the safety guidelines and/or operational instructions in this manual may result in serious personal injury, serious injury to another person, or damage to the airsoft gun. Must be 18 years of age or older to purchase/operate the airsoft gun.

### EYE PROTECTION

Always wear proper eye protection while shooting, operating, and maintaining your airsoft guns. Failure to do so can lead to serious bodily injury.

### EAR PROTECTION

With noise levels exceeding 85dB(A), appropriate ear protection must be used to prevent any damages due to sound emissions. Failure to use proper ear protection can lead to permanent damage to your hearing or the hearing of those near you.



### CHOKING HAZARD

It is vital that the rifle and all accessories are kept away from small children as there are many small parts that could present a choking hazard to the child, which can lead to serious injury or death.

### FIREARM SAFETY RULES

Always assume that the airsoft gun is loaded. Never assume the chamber is empty based on memory or from someone else's word. An airsoft gun can still fire with the magazine removed.

### KEEP YOUR FINGER OFF THE TRIGGER

Remove your finger from the inside of the trigger guard until your sights are aligned on target and you are ready to fire. Failure to do so can lead to accidental discharges, and possible injury.

### MUZZLE CONTROL

Always keep the muzzle of the airsoft gun pointed in a safe direction. Never point the airsoft gun towards anything you do not intend to shoot. Never point an airsoft gun at another



person. Always point your airsoft gun in a safe direction or in an area designed to accommodate the firing of the gun without the risk of damage to life or property.

### KNOW YOUR TARGET AND ITS SURROUNDINGS (SAFETY DISTANCE)

Take note of objects in front of and beyond your target. Airsoft guns can shoot up to and beyond 150 feet/45.5 meters and may travel further than intended without an adequate backstop. Never shoot an airsoft gun directly at targets such as rocks, glass, water, or other hard surfaces that may ricochet BBs in unpredictable directions. This could lead to possible injury and unintended damage to property.



## Safety Is Your Responsibility

### Safety Protocols

#### Failure to Fire

If during use the gun fails to fire, malfunctions or misfires **DO NOT** look down the barrel! The BB that is jammed can be under pressure and may shot at any moment causing serious bodily harm. Make sure to use a cleaning rod to attempt removing whatever may be causing the jam.

#### Beware of Barrel Blockages

Always be sure to check that the airsoft gun does not have anything shrouding or blocking the barrel as this could lead to a malfunction and possibly cause damage to the airsoft gun.

#### Fire Select

It is important to make sure that whenever the gun is not in use or being transported that you keep the fire select in the safe position in order to minimize the chance for accidental discharges.



## General Maintenance and Care

#### Storage and Transport

It is very important while transporting the gun to make sure that the fire select is set to safe. Also make sure that the battery and magazine are both removed from the airsoft gun and stored safely, when transporting the gun. Make sure that you are also using an appropriate carrying case for the airsoft gun and other items. Never brandish your airsoft gun in public, it is extremely difficult to tell the difference between and airsoft gun and real firearm. When storing the gun, it is also important to disconnect the battery and magazine and make sure that the airsoft gun is stored in a location that a cannot be reached by a child.

#### Orange Tip

Any alteration of the coloration or markings required by state and/or federal law may be deemed illegal in a court of law. All risks and responsibility of any alteration to the product will be assumed by the operators, owners and/or user of the product. Also, modification or removal of the orange tip may void warranty.



### Hazards of Being Mistaken for a Real Firearm

Due to the nature and design of some airsoft guns, they may be mistaken as a real firearm. It is strongly advised to operate an airsoft gun in the safety and privacy of your own home, or at a legally sanctioned location or game field. Police, Peace Officers, and Law Enforcement Officers are trained to treat objects that resemble a firearm as one. In the event that you are approached by a Law Enforcement Official, completely comply with their instructions. Never point an airsoft gun at a Law Enforcement Official. Confrontation with a Law Enforcement Official may result in serious injury or death.

### Warranty and Service

#### Length of Warranty

When purchasing your Adaptive Armament airsoft gun, it will come with a 30-day warranty from the day of purchase. However, if you register the product with proof of purchase on the Adaptive Armament website, it will extend your warranty to 90 days.

### Valid Warranty Claims

Except as specified below, this warranty covers all defects in material and workmanship in Adaptive Armament products occurring during the above warranty periods. The following are not covered by the warranty: (1) Any product which is not imported and distributed in the U.S.A. by Adaptive Armament, Inc. (2) Any products not purchased in the U.S.A. from an Adaptive Armament authorized dealer. If you are uncertain as to whether a dealer is an Adaptive Authorized Seller, please contact Adaptive Armament, Inc. as listed above). (3) Damaged deterioration or malfunction resulting from: a) Accident, act of nature, abuse, misuse, neglect, unauthorized product repair, opening of or modification or failure to follow instructions supplied with the product. b) Repair or attempted repair by anyone not authorized by Adaptive Armament, Inc. c) Removal of the orange safety tip. (4) Use of damaged batteries or improperly sized or quality BB's, (5) Use in industrial, commercial, and/or professional applications.

### What Adaptive Armament Will Pay For



If during the applicable warranty period from the date of the original purchase your Adaptive Armament product is found to be defective by Adaptive Armament, Inc., Adaptive Armament, Inc. will repair, at its discretion by providing new product or repairing the existing product without any cost to the consumer for parts of labor.

#### How to Obtain Warranty

If your product needs service, it may be taken or shipped to Adaptive Armament, Inc. The following procedures apply whenever your unit must be transported for warranty service:

You are responsible for transporting your unit or arranging for its transportation.

You must go to Help Desk at [www.adaptivearmament.com/warranty](http://www.adaptivearmament.com/warranty) to obtain an RMA number.

THE RMA NUMBER MUST BE CLEARLY MARKED ON THE OUTSIDE OF THE PACKAGE. PACKAGES WITHOUT AN RMA NUMBER CLEARLY MARKED WILL BE REFUSED AND RETURNED TO THE SENDER.



• If shipment of your unit is required; you must pay the initial shipping fee, but we at Adaptive Armament will pay the return shipping charge if the repairs are covered by the warranty.

• WHEN RETURNING YOUR UNIT FOR WARRANTY SERVICE, A COPY OF THE ORIGINAL SALES RECEIPT MUST BE ATTACHED.

• You must include the following: RMA number, your name, address, daytime telephone number, model and serial number (if applicable) of the product and a description of the problem.



NOTE: THE RMA NUMBER MUST BE CLEARLY MARKED ON THE OUTSIDE OF THE PACKAGE. PACKAGES WITHOUT AN RMA NUMBER CLEARLY MARKED WILL BE REFUSED AND RETURNED TO SENDER. NO EXCEPTIONS



## Loading the Magazine(High-Cap)

### High-Cap


1. Place the hi-cap magazine with the trap door (A) facing upward. Open the trap door and dispense BBs into the BB well.
2. When full, close the trap door and turn the winding wheel (B) forward until the 'clicking' changes tone.



**DO NOT OVER LOAD THE MAGAZINE**




## Fire Selector



### Safety Setting

(The trigger can not be pulled)


Always set lever to SAFE position when gun is not in use.



### Semi Auto

(Single Shot)

The gun will fire one shot each time the trigger is pulled.



### Full Auto

(Automatic Shot)

The gun will fire continuously while the trigger is depressed.



**Safety Tip:** Always make sure when not using the airsoft gun to keep the fire select in the “safe” position to lower the chances of an accidental discharge.




**DO NOT ENGAGE THE TRIGGER WHILE SWITCHING BETWEEN MODES ON THE FIRE SELECTOR.**

### Hop-Up System Adjustment

- Pull the charging handle to the rear to open ejection port and reveal Hop-Up adjustment dial. The slide will lock back to make for easy adjustment.
- Turn the Hop-Up adjustment dial forward to increase hop-up. Turn the Hop-Up adjustment dial backward to decrease hop-up.
- Once you are done adjusting the hope hit the bolt release located above the trigger.
- Excessively turning of the Hop-Up adjustment dial forward can cause Airsoft BBs to jam. Continued firing with a jammed barrel will cause damage to the gearbox.











- When jamming occurs, immediately stop shooting and turn the Hop-Up adjustment dial backward to decrease hop. Remove the jammed Airsoft BBs.







<p>● Wear protective eye wear &amp; face mask when using AirSoft airguns.</p> <p><small>Certified shooting Safety goggles</small></p> 	<p>● NEVER brandish or fire AirSoft airguns at animal or people beyond a certified and regulated AirSoft Sport arena. Brandishing a gun in public is against the law, serious consequences could arise.</p> 	
<p>● Read and understand the operating and safety manual before using your AirSoft airguns.</p> 	<p>● Do not look directly into the gun barrel to avoid accidental discharge of BB.</p> 	<p>● Be aware of your Surroundings to avoid accidents.</p> 
<p>● ALWAYS transport AirSoft airguns inside a locked carrying case. Make sure it's unloaded. Never carry your AirSoft Sport Gun in open view, as a concealed weapon, or brandish an AirSoft airguns in public.</p> 	<p>● Do not disassemble or modify your AirSoft airguns. Doing so will void all warranty. Service by authorized centers only. Removal of the orange Safety barrel marking is a federal offense.</p> 	<p>● Always install safety barrel plug when you are not using your AirSoft airguns.</p>  <p><small>Optional part</small></p>